

***ZZ* Cruiser**

E – 023

USER MANUAL

INSTRUCTION

1. To prolong motor life, push start the scooter before applying power.
2. Power handle returns to 'off' when released.
3. Release power handle before applying brake. Do not apply power when brake is on.
4. Charge battery and discharge at least once every 90 days.
5. Check tire pressure regularly.
6. Do not leave the scooter in direct hot sun for long periods.
7. Operate safely and in good weather only, use safety gear including helmet.
8. Obey the law in your city and state in all operations.
9. You are responsible for operating safely and seller assumes no liability for misuse or operator negligence.


Note: Riding up a steady incline for a prolonged periods of time will cause the controller to automatically cut power to the motor to avoid burn out. In such a case let the motor cool for about 2-3 minutes before turning back on.

IMPORTANT CHARGER AND BATTERY SAFETY INSTRUCTIONS CHARGING INSTRUCTIONS


1. Lay scooter flat with on/off switch in 'off' position.
2. Plug charger cord into scooter first, then plug into 110V, 120V, 220V, or 240V outlet.
3. Charge for 6-8 hours. The LED will be red during charging and when fully charged, the LED will turn green.
4. Do not overcharge, unplug unit after 8 hours to avoid overheating risks.
5. Charge unit after low charge warning and every 90 days.

BATTERY INSTRUCTIONS

1. Change the battery if any leaks, breaks or cracks appear.
2. Do not touch the battery liquid solution, flush with water if contact is made.
3. Dispose of battery according to state and local laws.




Entire scooter



Take out scooter from cartons

E-023 GENERAL CONNECTION DIAGRAM

Wiring Diagram



Basic functions and specifications

Material: Fiber glass deck and steel body

Dimensions: 33 × 22.86 × 106 cm

Gross weight: 21.09 kgs

Net weight: 18.33 kgs

Maximum speed: 19.31 kmh

Average travel distance: 17.7 kms

Power-driven max.load capacity: 90.72 kgs

After every charging: To travel for 1 consecutive hour

Brake: Handle control to rear wheel by drum brake

Tire: Airless tire

CHARGER

Moder No.	Input	Output	Charging time
AC0224A	100V~240V ~1.2 A	24.0V ~ 1.0A	6~8 Hours


MOTOR

Moder No.	Rated voltage	Rated current	Output power
RPD-24	DC24V	15.5A	200W

BATTERY

	Nominal capacity	Voltage	Weight	Charging time
Lead acid storage battery	9AH	24V	8kg	>=250 times

SIMPLE INSTALLATION DRAWING




Unfold the ZZ Cruiser


1. Lift the quick release lever and push down the safety lever.
2. To unfold the handlebar column grasp it in the middle and raise it to an upright position. (to uplift the safety lever to make sure it's at the right position)
3. Push the quick release lever down to lock it into the position.

Folding the ZZ Cruiser


1. Lift the quick release lever
2. Push down the safety lever & lay the handlebar down on top of the deck.
3. Uplift the safety lever to lock the handlebar at the folding position.
4. Push down the quick release.



1. set handlebar upright and secure
2. Press the spring button and insert handles spring button holes in the T shaped handlebar.
3. Ensure speed control on right, brake on left.



Press the clip



adjust up and down

MAINTENANCE

1. Inspect the entire scooter before each use; check the brake, speed control, belt and wheels, including tire pressure.
2. If you hear any unusual noise, stop and check the motor and do not operate if improper noises.
3. Clean the scooter regularly and avoid long hot sun exposure.
4. Lubricate the front and rear axle, chain and all turning parts.

[see charg 1]

chart 1 Termly Inspection and Maintenance Range

	300miles	600miles	12miles	1800miles
Brake	A	I	A	I
Different control pull lines	L	I	L	I
Tire	I	I	I	I
All the connect lines	I	I	T	I
Front fork and frame	I	I	I	I

ATTENTION: I:inspect, clean and adjust T:tighten A:adjust

L:lubricate