



Elstar Products Pty. Ltd.  
18/116 McCredie Road  
Guildford West NSW 2161

phone: (+61)2 9632 7757  
fax: (+61)2 9632 7759  
email: [info@elstars.com.au](mailto:info@elstars.com.au)  
web: <http://www.elstars.com.au>

## THROTTLE REPLACEMENT INSTRUCTIONS

1. Open the plastic cover, first unscrewing four screws.
2. Find the throttle connection to the control box and unclip the connection. The connection has a three-line clip (green, black, red).
3. Take off the broken throttle by loosening the little black screw underneath the handle ring, using a key screwdriver.
4. Pull out the throttle and wires.
5. Put on the new throttle and tighten it to the handle bar.
6. Insert throttle wire into the control box.
7. Put three wires into the connection clip in the same order as it was (green, black, red).
8. Connect the throttle interface to the control box and test the throttle.
9. Close the plastic cover.
10. Secure cover with four screws.